

FAQs:

Get a Part-66 licence, Part-66, Continuing Airworthiness, Regulations

Question:

How to get an EASA Part-66 Licence (Category B1 or B2)?

Answer:

- 1. In order to get an EASA Part-66 AML (Aircraft Maintenance License), an applicant needs:
 - i. Basic knowledge (66.A.25);
 - ii. Basic experience (66.A.30).
- 2. In order to get an aircraft type rating TR endorsed in the AML, an applicant needs:
 - i. Type Training (Theoretical and Practical) (66.A.45)
 - ii. On-the-job Training (OJT) for the first TR (66.A.45).

The following two schemes depict the most common paths and are for information only.

- The first scheme applies to Group 1 aircraft (B1 and B2 licence categories).
- The second scheme applies to other than Group 1 aircraft (B1 and B2 licence categories). NOTE: Aircraft groups are described in 66.A.5.

These schemes do not override Part-66 requirements nor capture all the possibilities (various licences, educations and experiences). The start and end of each phase can vary depending on individual cases.

For further and detailed information:

- Refer to Part-66 and related AMC/GM; and
- Consult the Competent Authority where you intend to apply for the AML.


NOTE:

An AML issued by a country other than EASA Member States cannot be rendered valid as EASA Part-66 AML.

NOTE:

Part-66 licences issued by the countries other than EASA Member States are not mutually recognised in the European system.





Type examination

Max. 3 years [Appendix III points 1 and 5]

Click on the pictures to zoom in.

Max. 10 years [66.A.25 and 66.A.30(f)]

Last updated:

02/02/2021

Link:

https://www.easa.europa.eu/mt/faq/21067